DigiBoard

CD Wrap - Perf & Tab

003R96924

1. Contents

2 up CD Wraps x 110 Sheets

2. Artwork Guidelines

1. Allow at least 3mm bleed over all perforations.
2. Use the outer line of the artwork template to centre your artwork on the sheet.
3. View the artwork template for more information.

3. Printing Guidelines

1. Print on the coated side of the stock.
2. This stock should only be used from the bypass tray and in simplex mode.
3. Maximum tray load should be 30 sheets.
4. Print with the arrow indicator on the leading edge, as shown.

4. Finishing - Option 1

Use this option if you are finishing a very low quantity.

1. Carefully tear into the sheet, and following the perforated line tear away the waste (shown in grey).
2. Where possible pre-fold the perforated line to weaken as you are tearing.
3. Completely remove one wrap before tearing out the second.

Go to step 6.

5. Finishing - Option 2

Use this option if you are finishing multiple copies.

1. Guillotine 2mm inside 2 of the perforated edges of each CD Wrap as indicated in Fig.1 & 2
2. Tear away the waste shown in grey - where possible pre-fold the perforated line to weaken as you are tearing. (Fig.3)

Fig. 1

Fig. 2

Fig. 3

6. Folding Guidelines

1. Lay the CD Wrap print side down on a flat surface.
2. Carefully fold the flaps towards you in the sequence indicated in the illustration Fig. 1
3. Tuck the curved edge ❶ into the slot ❷ as shown in the illustration Fig.2.
4. The completed wallet is shown in Fig. 3.

Fig. 1

Fig. 2

Fig. 3